Cowon D2
Audible User Guide

Requirements & Tech Specs

- Windows XP with SP 2 or Vista
- Windows Media Player 11.
- **Audible Formats:** 3 4
- **Capacities Available:** 1GB, 2GB, & 8GB
- **Bookmarking:** No
- **Section Navigation:** Yes
- **Variable Playback Speed:** No
- **FM Radio:** Yes
- **Video:** Yes
- **Removable Battery:** No

How To's:

A. **Playback:** How do I locate/play Audible content on the device?

1. From the Main Menu, select **Music** to go to the Music menu.
2. Next, tap the screen to display additional options and select **Browser** in the lower left corner of the screen.
3. Then, select **Music List** on the left side of the screen.
4. Select **Mode** in the lower left corner of the screen , then select **Music Library** on the left hand side of the screen.
5. Scroll down and select **Audible**.
6. Finally, select the title that you want to play.
.

B. **Rewind/Fast-Forward:** How do I rewind/fast-forward through my Audible content on the device?

1. **Rewinding:** While a title is playing tap the screen to bring up the menu and hold down the **Rewind** button.
2. **Fast-Forwarding**: While a title is playing tap the screen to bring up the menu and hold down the **Fast Forward** button.

.

C. **Section Navigation:** How do I use section navigation?

1. Audible section navigation must be turned on to navigate by sections. To turn this on from the Main Menu select **Settings**.
2. Next select **General**.
3. Scroll down and select **Audible Section Navigate** to enable section navigation. (When enabled, **Audible Section Navigate** will be checked).
4. While a title is playing, tap the screen to bring up the menu.
a. Press the **Rewind (<<)** button to return to the previous section.
b. Press the **Fast Forward (>>)** button to skip to the next section.
.

Buttons and Functions

D2 has a touchscreen feature and you can control it directly by touching the screen.